

ISO 13628-8 Class 1-4 (API 17D) Gauging Tool

Torque Tool Accessories.



DESCRIPTION

The Class 1-4 Gauging Tool has been developed to test interfaces. The interfacing part of the tool is identical to the Class 4 Torque Tool and comes with a set of class 1-4 sockets as standard. This allows rapid interface checks without the weight and hydraulic requirements of using a real torque tool.

The tool can be turned by hand from a handle at the rear, or can be fitted with a shaft at the rear to accept a torque wrench, so that torque can be applied to the valve. Locking wings are provided to check the latching operation.

FEATURES

Used to check ISO 13628-8 Class 1-4 Interface

Manually operated Torque Tool.

Latching Wings

Rotating Socket

Lightweight

Supplied in offshore suitable transit case



ISO 13628-8 Class 1-4 (API 17D) Gauging Tool

Torque Tool Accessories.

SPECIFICATIONS

Torque Interface: ISO 13628-8 fig 18 Class 1-4

Maximum Torque: 100Nm

WHAT'S IN THE BOX

Gauging Tool

Class 1 & 2 Socket (11/16" Sq) Class 3 socket (1-1/8" Sq) Class 4 socket(1-1/2" Sq)


Rotation Handle


Socket for wrench input (1" square

drive)

PART NUMBERS & OPTIONS

A019-958-452 Gauging Tool





www.f-e-t.com/subseatooling

Datasheet #A001-350-007 issue 8